



Single lever handle Lavatory faucet
Model NO.: 415G-CP
415G-BN
415G-ORB


Preparation / Assembly




Shut off water supplies. Remove old faucet. Clean sink surface in preparation for the new faucet.




Place optional Flange at the bottom of the new faucet before position faucet through mounting hole.



Remove the 2 screws from locking nut. From under the sink, install the rubber washer, steel washer, and locking nut onto the shank. Tighten the locking nut with a basin wrench or socket tool and install the 2 screws to secure the faucet in place.



Apply pipe tape onto threads of water supplies. Use wrench when tightening the hose connection, do not overtighten.



Important: After installation is completed. Turn on water supply and allow both hot and cold water to run for at least one minute each. While water is running, check for leaks. Reinstall Aerator. Your new faucet is now ready to use.

INSTRUCTION

Tools:

- Adjustable Wrench
- Pliers
- Pipe Wrench
- Screwdriver
- Teflon Tape
- 1 3/8" Basin Wrench or
- 1 11/32" Shower Valve Socket Wrench



Maintenance:

Your new lavatory faucet is designed for years of trouble-free performance.

Keep it looking new by cleaning it periodically with a soft cloth. Avoid abrasive cleaners, steel wool and harsh chemicals as these will dull the finish and void your warranty.

Model NO.: GF-145G-CP
GF-145G-BN
GF-145G-ORB

